

# STEAM PUNK

MODEL:SP6  
PC GAMING CASE



## FEATURES:

1. RIGHT&LEFT PANEL WITH ARGB DANCING BAR



REVISED HISTORY  
Version 1.2

Edited by EVE  
2022.11




# SPECIFICATIONS

MODEL	SP6
DIMENSIONS(L*W*H)	STRUCTURE:335*255*320MM PRODUCT: 365*255*360MM PACKAGE: 435*330*450MM
STRUCTURE THICKNESS	0.7MM
MATERIALS	SPCC 0.7MM LEFT SIDE PANEL: TEMPERED GLASS FRONT PANEL: METAL MESH
FORM FACTOR	M-ATX\ITX
DRIVE BAYS	5.25" CD ROM: 0 ①3.5" HDD: 1+2.5" SSD: 2 ②3.5" HDD: 0+2.5" SSD: 3
CPU MAX L	140MM
VGA MAX L	320MM
I/O PANEL	USB3.0*2+HD AUDIO
PCI CARD SLOT	4
FAN SUPPORT	FRONT SIDE: 2*12CM TOP: 2*12CM
LIQUID COOLING SUPPORT	TOP: 24CM
POWER SUPPLY SUPPORT	BOTTOM MOUNT
WEIGHT	N.W.: 5.5KG G.W.: 6.5KG



PC GAMING CASE  
SP6

# PICTURES




PC GAMING CASE  
SP6

# USER MANUAL



1STPLAYER GAMING CASE  
首席玩家游戏机箱  
USER MANUAL 说明书

## ASSEMBLY VIEW 装配视图



## DANCING BAR MODE INTRODUCTION 音乐律动模式说明

NO. 序号	MODE 模式	DIRECTION 方向	EACH MODE CONTAINS 9 DIFFERENT COLOUR 每个模式都有9种颜色选择
1	BOTTOM-UP BAR, NO WHITE DOTS 正向柱状, 无白点	----->>>	1.FULL COLOUR 全彩色
2	BOTTOM-UP BAR, 2 WHITE DOTS 正向柱状, 2个白点	----->>>	2.COLOUR FADING 渐变
3	SIDE TO MIDDLE BAR, NO WHITE DOTS 双向柱状, 无白点	<<<----- ----->>>	3.RED 单色红
4	SIDE TO MIDDLE BAR, 1 WHITE DOT 双向柱状, 1个白点	<<<----- ----->>>	4.GREEN 单色绿
5	SIDE TO MIDDLE BAR, NO WHITE DOTS BUT WITH BASE COLOUR 双向柱状, 不带白点带底色	<<<----- ----->>>	5.BLUE 单色蓝
6	BOTTOM-UP BAR, 1 WHITE DOTS 正向柱状, 1个白点	----->>>	6.YELLOW 单色黄
7	SYNCHRONIZED TWO BAR WITH SAME DIRECTION 单向两段同步	<<<----- ----->>>	7.PURPLE 单色素
8	TWO BAR OPPOSITE 单向两段同步	>>>----- -----<<<	8.CYAN 单色青
			9.WHITE 单色白

## DANCING BAR MODE AND ARGB MODE: 律动模式与ARGB模式切换:

DANCING BAR MODE/律动模式:  
PRESS TO CHANGE TO THE DANCING BAR MODE.  
短按 [ ] , 切换律动灯光形态

ARGB MODE/ARGB模式:  
MOTHERBOARD SYNCHRONIZATION  
跟随主板灯光

TURN OFF/关灯操作:  
LONG PRESS THE BUTTON FOR 4 SECONDS, WHEN THE WHITE LIGHT  
FLASHES 2 TIMES, IT WILL BE TURNED OFF.  
长按 [ ] 4秒, 白光重复闪烁2下, 关机

TURN ON/开灯操作:  
LONG PRESS THE BUTTON FOR 4 SECONDS,  
WHEN THE WHITE LIGHT FLASHES 2 TIMES IT WILL, TURN ON  
长按 [ ] 4秒, 白光闪烁2次, 开灯



PC GAMING CASE  
SP6

# USER MANUAL

## A. MOTHERBOARD/主板

1. THE HOLES OF MOTHERBOARD SCREW ALIGN WITH THE HEXAGON PILLARS  
主板螺丝孔位对准六角铜柱
2. FIX THE MOTHERBOARD AND CASE WITH MOTHERBOARD SCREW  
使用主板螺丝把主板与机箱固定
3. CPU MAX L: 140MM  
机箱支持140MM高CPU散热器

MOTHERBOARD SPECIFICATIONS/主板规格




## B. VGA CARD/显卡

1. INSERT THE VGA CARD TO THE PCI-E X4 CARD SLOT OF MOTHERBOARD  
显卡插入主板PCI-E X4卡槽
2. FIX THE VGA CARD WITH HEXAGONAL SCREWS  
六角螺丝固定显卡
3. RESERVING THE VGA CARD SLOTS FOR THE CASE, WHICH CAN ADJUST IT SELF  
ACCORDING TO THE OUTPUT PORT OF VGA CARDS  
机箱预留显卡卡槽,可根据显卡输出口自行调节
4. VGA MAX L: 320MM  
机箱支持320MM长

## C. POWER SUPPLY/电源

1. PSU BOTTOM MOUNT  
下置电源仓
2. THE HOLES OF PSU ALIGN WITH THE RESERVED HOLE FOR CASE  
电源孔位对准机箱预留的电源孔位
3. FIX WITH THE HEXAGONAL SCREWS  
用六角螺丝固定



## D. HDD

1. SUPPORT 3.5"HDD\*1 支持3.5"HDD\*1
2. THE SCREW HOLES OF HDD ALIGN WITH THE HDD HOLES, LOCKED THE HDD SCREW/HDD  
螺丝孔位对准HDD孔位,锁上HDD螺丝

## E. SSD

1. SUPPORT 2.5"SSD\*2 支持2.5"SSD\*2
2. THE HOLES OF SSD ALIGN WITH THE RESERVED HOLE FOR CASE/SSD螺丝孔位对准HDD孔位,锁上HDD螺丝
3. FIX SSD WITH THE MOTHERBOARD SCREWS/用主板螺钉固定SSD

## F. LIQUID COOLER/冷排

1. TOP: 24CM 支持顶部 24CM 冷排

## FAN/风扇

1. FRONT: 2\*12CM 支持前置2PCS 12CM 机箱风扇
2. TOP: 2\*12CM 支持顶部2\*PCS 12CM 机箱风扇



PC GAMING CASE  
SP6