

STEAM PUNK

MODEL:SP7
PC GAMING CASE



FEATURES:

- 1.FRONT PANEL WITH ARGB DANCING BAR
- 2.305MM WIDE BODY CASE
- 3.SUPPORT VGA CARD VERTICAL PLUG
- 4.SUPPORT 12CM FAN 9PCS
- 5.SUPPORT 360 COOLING
- 6.DOUBLE-SIDED TEMPERED GLASS



REVISED HISTORY

Version 1.6

Edited by EVE

2022.11


SPECIFICATIONS

MODEL	SP7
DIMENSIONS(L*W*H)	STRUCTURE:425*308*362MM PRODUCT: 425*308*380MM PACKAGE: 455*395*535MM
STRUCTURE THICKNESS	0.8MM
MATERIALS	SPCC 0.8MM F&L SIDE PANEL: TEMPERED GLASS
FORM FACTOR	ATX/M-ATX
DRIVE BAYS	5.25" CD ROM: 0 3.5" HDD: 2+2.5" SSD: 1
CPU MAX H	185MM
VGA MAX L	400MM(DESIGNED FOR MOUNTING GPU'S VERTICALLY)
I/O PANEL	USB3.0*2+TYPE-C*1+HD AUDIO
PCI CARD SLOT	7+3
FAN SUPPORT	ON THE LEFT OF THE FRONT SIDE: 2*12CM/2*14CM TOP: 3*12CM/2*14CM REAR: 1*12CM BOTTOM: 3*12CM/2*14CM
LIQUID COOLING SUPPORT	TOP: 36CM FRONT: 24CM/28CM BOTTOM: 36CM
POWER SUPPLY SUPPORT	BOTTOM MOUNT(LIMIT IS 200 MM LONG)
WEIGHT	N.W.: 7.6KG G.W.: 8.2KG




**PC GAMING CASE
SP7**

PICTURES



PC GAMING CASE
SP7

USER MANUAL



1STPLAYER GAMING CASE

首席玩家游戏机箱
USER MANUAL 说明书
WWW.1STPLAYER.COM

• DANCING BAR MODE INTRODUCTION

音乐律动模式说明

NO. 序号	MODE 模式	DIRECTION 方向	EACH MODE CONTAINS 9 DIFFERENT COLOUR 每个模式都有9种颜色选择
1	BOTTOM-UP BAR, NO WHITE DOTS 正向柱状, 无白点	----->>	1.FULL COLOUR 全彩色
2	BOTTOM-UP BAR, 2 WHITE DOTS 正向柱状, 2个白点	----->>	2.COLOUR FADING 渐变
3	SIDE TO MIDDLE BAR, NO WHITE DOTS 双向柱状, 无白点	<----- ----->>	3.RED 单色红
4	SIDE TO MIDDLE BAR, 1 WHITE DOT 双向柱状, 1个白点	<----- ----->>	4.GREEN 单色绿
5	SIDE TO MIDDLE BAR, NO WHITE DOTS BUT WITH BASE COLOUR 双向柱状, 不带白点带底色	<----- ----->>	5.BLUE 单色蓝
6	BOTTOM-UP BAR, 1 WHITE DOTS 正向柱状, 1个白点	----->>	6.YELLOW 单色黄
7	SYNCHRONIZED TWO BAR WITH SAME DIRECTION 单向两段同步	<----- <----- >>	7.PURPLE 单色紫
8	TWO BAR OPPOSITE 单向两段同步	>>----- <-----<<	8.CYAN 单色青
			9.WHITE 单色白

DANCING BAR MODE AND ARGB MODE:

律动模式与ARGB模式切换:

LONG PRESS THE BUTTON FOR 2 SECONDS : WHITE LIGHT FLASHES 2 TIMES,
THEN TWO MODES CAN SWITCH FREELY.

长按 2S按键, 白光闪烁2下, 两种模式自由切换

DANCING BAR MODE/律动模式:

PRESS TO CHANGE TO THE DANCING BAR MODE.

短按 , 切换律动灯光形态

ARGB MODE/ARGB模式:

MOTHERBOARD SYNCHRONIZATION

跟随主板灯光

TURN OFF/关灯操作:


LONG PRESS THE BUTTON FOR 4 SECONDS , WHEN THE WHITE LIGHT
FLASHES 2 TIMES , IT WILL BE TURNED OFF.

长按 4秒, 白光重复闪烁2下, 关机

TURN ON/开灯操作:

PRESS THE BUTTON

短按



D. HDD

1. SUPPORT 3.5"HDD*2

支持3.5"HDD*2

2. THE SCREW HOLES OF HDD ALIGN WITH THE HDD HOLES, LOCKED
THE HDD SCREW

HDD螺絲孔位對準HDD孔位, 鎖上HDD螺絲

E. SSD

1. SUPPORT 2.5"SSD*2

支持2.5"SSD*2

2. THE HOLES OF SSD ALIGN WITH THE RESERVED HOLE FOR CASE
SSD孔位對準機箱的SSD預留孔位

3. FIX SSD WITH THE MOTHERBOARD SCREWS

用主板螺釘固定SSD

F. LIQUID COOLER/冷排

1.FRONT:24CM 支持前置24CM冷排

2.TOP&BOTTOM:36CM 支持頂置和下置36CM冷排

FAN/風扇

1. FRONT:2*12CM/2*14CM支持前置2*PCS 12CM/14CM機箱風扇

2. TOP:3*12CM/2*14CM支持頂部3*PCS 12CM/2*PCS 14CM機箱風扇

3. REAR:1*12CM支持後置1*PCS 12CM機箱風扇

4. BOTTOM: 3*12CM/2*14CM支持底部3*PCS 12CM/2*PCS 14CM機箱風扇




PC GAMING CASE
SP7

USER MANUAL

• ASSEMBLY VIEW

裝配視圖



A. MOTHERBOARD/主板

1. THE HOLES OF MOTHERBOARD SCREW ALIGN WITH THE HEXAGON PILLARS
主板螺絲孔位對準六角銅柱
2. FIX THE MOTHERBOARD AND CASE WITH MOTHERBOARD SCREW
使用主板螺絲把主板與機箱固定
3. CPU MAX H: 160MM
機箱支持160MM高CPU散熱器

MOTHERBOARD SPECIFICATIONS/主板規格

ATX	M-ATX
-----	-------

B. VGA CARD/顯卡

1. INSERT THE VGA CARD TO THE PCI-E X16 CARD SLOT OF MOTHERBOARD
顯卡插入主板PCI-E X16卡槽
2. FIX THE VGA CARD WITH HEXAGONAL SCREWS
六角螺絲固定顯卡
3. RESERVING THE VGA CARD SLOTS FOR THE CASE ,WHICH CAN ADJUST IT SELF ACCORDING TO THE OUTPUT PORT OF VGA CARDS
機箱預留顯卡卡槽，可根據顯卡輸出口自行調節
4. VGA MAX L: 400MM
機箱支持400MM長顯卡

C. POWER SUPPLY/電源

1. PSU BOTTOM MOUNT
下置電源倉
2. THE HOLES OF PSU ALIGN WITH THE RESERVED HOLE FOR CASE
電源孔位對準機箱預留的電源孔位
3. FIX WITH THE HEXAGONAL SCREWS
用六角螺絲固定



PC GAMING CASE
SP7