



#### Feature:

- 12 cm FDB low noise fan
- EFF. high as 90% under typical loading
- Comply with ErP LOT 6
- Multi protections: OVP, OPP, UVP, SCP











#### SAFETY AND PROTECTION

Your new power supply unit comes equipped with multiple protective features to ensure safe and reliable operation:

**Under-Voltage Protection (UVP)** shuts the PSU off if the voltage the PSU is providing to the PC drops below accepted values.

**Over-Voltage Protection (OVP)** Monitors 12V, 5V, and 3.3V outputs. Automatically shuts down the PSU if voltage exceeds safe levels.

**Over-Power Protection (OPP)** Turns off the PSU if power draw reaches 115-135% of the rated capacity.

**Short-Circuit Protection (SCP)** Activates when output impedance falls below 0.1 ohms. Protects against shorts between rails or to ground, preventing damage to the PSU and system components.

These safety mechanisms work together to protect your computer system and the power supply itself from potential electrical hazards. For optimal performance and longevity, always operate your PSU within its rated specifications.







# **PS-300FK SPECIFICATIONS**

MODEL	PS-300FK	
POWER OUTPUT	300 W	
INPUT VOLTAGE	200 - 240V	
INPUT CURRENT	8 A	
INPUT FREQUENCY	50 - 60 Hz	
EFFICIENCY	90% at full load	
DIMENSIONS (L x W x H)	140 x 150 x 86 mm	
MODULAR	Non-modular	
PFC	Passive PFC	
FAN SIZE	120 mm FDB	
PROTECTIONS	UVP, OVP, OPP, SCP	
REGULATORY	CE/FCC/RoHS/CCC/EAC/CB/RCM	
WARRANTY	3 years	

DC OUTPUT	MAX LOAD (A)	MAX OUTPUT (W)
+3.3V	15	100
+5V	15	100
+12V	25	300
+5VSb	2.5	12.5
-12V	0.3	3.6



# **PS-400FK SPECIFICATIONS**

MODEL	PS-400FK	
POWER OUTPUT	400 W	
INPUT VOLTAGE	200 - 240V	
INPUT CURRENT	8 A	
INPUT FREQUENCY	50 - 60 Hz	
EFFICIENCY	90% at full load	
DIMENSIONS (L x W x H)	140 x 150 x 86 mm	
MODULAR	Non-modular	
PFC	Passive PFC	
FAN SIZE	120 mm FDB	
PROTECTIONS	UVP, OVP, OPP, SCP	
REGULATORY	CE/FCC/RoHS/CCC/EAC/CB/RCM	
WARRANTY	3 years	

DC OUTPUT	MAX LOAD (A)	MAX OUTPUT (W)
+3.3V	15	100
+5V	15	
+12V	33	396
+5VSb	2.5	12.5
-12V	0.3	3.6



# **PS-500FK SPECIFICATIONS**

MODEL	PS-500FK	
POWER OUTPUT	500 W	
INPUT VOLTAGE	200 - 240V	
INPUT CURRENT	8 A	
INPUT FREQUENCY	50 - 60 Hz	
EFFICIENCY	90% at full load	
DIMENSIONS (L x W x H)	140 x 150 x 86 mm	
MODULAR	Non-modular	
PFC	Active PFC	
FAN SIZE	120 mm FDB	
PROTECTIONS	UVP, OVP, OPP, SCP	
REGULATORY	CE/FCC/RoHS/CCC/EAC/CB/RCM	
WARRANTY	3 years	

DC OUTPUT	MAX LOAD (A)	MAX OUTPUT (W)
+3.3V	15	100
+5V	15	100
+12V	41	492
+5VSb	2.5	12.5
-12V	0.3	3.6



# **PS-550FK SPECIFICATIONS**

MODEL	PS-550FK	
POWER OUTPUT	550 W	
INPUT VOLTAGE	200 - 240V	
INPUT CURRENT	8 A	
INPUT FREQUENCY	50 - 60 Hz	
EFFICIENCY	90% at full load	
DIMENSIONS (L x W x H)	140 x 150 x 86 mm	
MODULAR	Non-modular	
PFC	Active PFC	
FAN SIZE	120 mm FDB	
PROTECTIONS	UVP, OVP, OPP, SCP	
REGULATORY	CE/FCC/RoHS/CCC/EAC/CB/RCM	
WARRANTY	3 years	

DC OUTPUT	MAX LOAD (A)	MAX OUTPUT (W)
+3.3V	15	100
+5V	15	100
+12V	45	540
+5VSb	2.5	12.5
-12V	0.3	3.6



# **PS-600FK SPECIFICATIONS**

MODEL	PS-600FK	
POWER OUTPUT	600 W	
INPUT VOLTAGE	200 - 240V	
INPUT CURRENT	8 A	
INPUT FREQUENCY	50 - 60 Hz	
EFFICIENCY	90% at full load	
DIMENSIONS (L x W x H)	140 x 150 x 86 mm	
MODULAR	Non-modular	
PFC	Active PFC	
FAN SIZE	120 mm FDB	
PROTECTIONS	UVP, OVP, OPP, SCP	
REGULATORY	CE/FCC/RoHS/CCC/EAC/CB/RCM	
WARRANTY	3 years	

DC OUTPUT	MAX LOAD (A)	MAX OUTPUT (W)
+3.3V	15	100
+5V	15	100
+12V	50	600
+5VSb	2.5	12.5
-12V	0.3	3.6



# **PS-650FK SPECIFICATIONS**

MODEL	PS-650FK	
POWER OUTPUT	650 W	
INPUT VOLTAGE	200 - 240V	
INPUT CURRENT	10 A	
INPUT FREQUENCY	50 - 60 Hz	
EFFICIENCY	90% at full load	
DIMENSIONS (L x W x H)	140 x 150 x 86 mm	
MODULAR	Non-modular	
PFC	Active PFC	
FAN SIZE	120 mm FDB	
PROTECTIONS	UVP, OVP, OPP, SCP	
REGULATORY	CE/FCC/RoHS/CCC/EAC/CB/RCM	
WARRANTY	3 years	

DC OUTPUT	MAX LOAD (A)	MAX OUTPUT (W)
+3.3V	15	100
+5V	15	100
+12V	54	648
+5VSb	2.5	12.5
-12V	0.3	3.6



# **PS-700FK SPECIFICATIONS**

MODEL	PS-700FK	
POWER OUTPUT	700 W	
INPUT VOLTAGE	200 - 240V	
INPUT CURRENT	10 A	
INPUT FREQUENCY	50 - 60 Hz	
EFFICIENCY	90% at full load	
DIMENSIONS (L x W x H)	140 x 150 x 86 mm	
MODULAR	Non-modular	
PFC	Active PFC	
FAN SIZE	120 mm FDB	
PROTECTIONS	UVP, OVP, OPP, SCP	
REGULATORY	CE/FCC/RoHS/CCC/EAC/CB/RCM	
WARRANTY	3 years	

DC OUTPUT	MAX LOAD (A)	MAX OUTPUT (W)	
+3.3V	15	100	
+5V	15		
+12V	58	696	
+5VSb	2.5	2.5 12.5	
-12V	0.3	3.6	



# **PS-750FK SPECIFICATIONS**

MODEL	PS-750FK	
POWER OUTPUT	750 W	
INPUT VOLTAGE	200 - 240V	
INPUT CURRENT	10 A	
INPUT FREQUENCY	50 - 60 Hz	
EFFICIENCY	90% at full load	
DIMENSIONS (L x W x H)	140 x 150 x 86 mm	
MODULAR	Non-modular	
PFC	Active PFC	
FAN SIZE	120 mm FDB	
PROTECTIONS	UVP, OVP, OPP, SCP	
REGULATORY	CE/FCC/RoHS/CCC/EAC/CB/RCM	
WARRANTY	3 years	

DC OUTPUT	MAX LOAD (A)	MAX OUTPUT (W)	
+3.3V	15	100	
+5V	15		
+12V	62	744	
+5VSb	2.5	12.5	
-12V	0.3	3.6	



# **CABLE INFORMATION**

CONNECTORS	TOTAL LENGTH	QUANTITY
ATX Cable 24-pin (Motherboard)	600 mm	1
ATX12V Cable 8-pin (4+4 CPU)	600 mm	1
PCI-E Cable (6+2 GPU)	700 mm	1
SATA IDE Cable (SSD/HDD/Fan)	900 mm	2



#### **INSTALLATION GUIDE**

Before You Begin, ensure your system is powered off and unplugged from any power source.

#### Step 1: Removing the Existing PSU (Skip if building a new system)

- 1. Unplug the AC power cord from both the wall outlet and the current PSU.
- 2. Carefully disconnect all power cables from your components (GPU, motherboard, drives, etc.).
- 3. Remove the old PSU from your case following your chassis manual instructions.

#### Step 2: Installing Your New PSU

- 1. Verify the PSU's AC power cable is disconnected.
- 2. Mount the new PSU in your case using the provided screws.
- 3. Connect the main power cables:
  - Attach the 24-pin ATX cable to your motherboard.
  - Connect the CPU power cable (4-pin, 8-pin, or 4+4-pin) as required by your motherboard.
- 4. Connect component power cables:
  - SATA power cables to SSDs, HDDs, and optical drives.
- PCle power cables to your graphics card(s) if needed.
- Peripheral (Molex) cables to any components requiring them.
- 5. Double-check all connections are secure.
- 6. Organize cables for optimal airflow, using cable management features in your case.
- 7. Connect the AC power cord to the PSU, but don't plug it into the wall yet.

#### **Important Notes:**

- Use only the cables provided with your new PSU to ensure compatibility and safety.
- Refer to your motherboard and GPU manuals for specific power requirements.

After installation, ensure all components are properly connected before powering on your system.

